


RFR GBP rogrammableLedC ontroller

09.289SP.04266




Important: Read All Instructions P rior to Installation

Function introduction



Front side



4.5V(3xAAA battery)

Bottom side

Product Data


Output	RF signal
Operation Frequency	869.5/916.5/434MHz
Power Supply	4.5V(3xAAA battery)
Operating temperature	0-40°C
Relative humidity	8% to 80%
Dimensions	120x55x17mm

- Control 4 zones of RF receivers separately.
- RGBW color controller
- High sensitive & high stable, fast & precise color control.
- Compatible with all universal series RF receivers
- 1 receiver can be paired by max 8 different remote controls.
- Waterproof grade: IP20


Safety & W arnings

- This device contains AAA batteries that shall be stored and disposed properly.
- DO NOT expose the device to moisture.


Pair with RF receiver(Method 1)




Pair with RF receiver(Method 2)




Save color/scene/mode



Recall the saved colors/scenes



Program function




If you use multiple receivers, you have two choices:

Option 1: have all the receivers in the same zone, like zone 1



Option 2: have each receiver in a different zone, like zone 1, 2, 3 or 4



How to stop running mode of single color LED light caused by RGBW sender interference:

1. When pairing single color LED light to a single color remote, it might be interfered and paired by nearby RGBW senders, which might control the single color light into running mode. The running mode can not be stopped by the paired single color remote or by delete pairing.
2. Then we need this remote, and pair the remote to the receiver via above “**Pair with RF receiver(Method 2)**”, then touch the color wheel to stop the running mode.
3. Then delete pairing and pair the receiver to the single color remote again, it can be controlled by the remote again.