Technical Sheet

mad designers design 2013

MACROLUX

MACROLUX s.r.l.31020 San Vendemiano Treviso - Italia Via Padania, 67/69 t. +39 0438 470773 f. +39 0438 470295 p. iva 03547130264 macrolux@macrolux.net www.macrolux.it



MX1 45

Technical description

Modular System made of aluminum extrusion for fully recessed installation on plasterboard, surface-mounted or suspended.

The polycarbonate or prismatic diffuser is retracted to aprox. 21 mm from the edge of the profile to allow a more comfortable emission, lowering the forward luminance. Available in white ultra matt finishes, ultra matt black and satin anodized aluminum.

The system can be equipped with LED strips 24V and the power supply is remote.

Installation:

Fully recessed on plasterboard, surface mounted or suspended.

Dimensions:

MX1 45

P = 50 mm H = 64,5 mm

Finishings:



MX1_45

 $\underset{40}{\text{IP}} \stackrel{\text{(ii)}}{\Leftrightarrow} (\in \mathbb{A} \mathbb{Z})$

